

The Lenovo logo is displayed in white text on a black rectangular background.

Enabling the Secured-Core Feature of Microsoft Windows Server 2022 on Lenovo ThinkSystem Servers

Introduces the Secured-core feature of Windows Server 2022

Lists which Lenovo servers support Secured-core

Describes how to enable Secured-core on ThinkSystem servers

Shows how to check the status of Secured-core

Guiqing Li



Abstract

Secured-core is a new feature of Microsoft Windows Server 2022 that brings powerful threat protections together to provide multi-layer security across hardware, firmware, and the operating system. It uses the Trusted Platform Module 2.0 and System Guard to boot up Windows Server securely and minimize risks from firmware vulnerabilities.

To be certified for Secured-core, new server firmware protection features are required. Currently only ThinkSystem servers with 3rd Gen Intel Xeon Scalable processors are certified, however ThinkSystem servers with AMD EPYC 7003 Series processors are also planned in the near future.

This document introduces Secured-core feature, and shows users how to enable it on supported Lenovo® ThinkSystem servers. This paper is intended for IT specialists and IT administrators who are familiar with security features of Windows Server and want to enable Secured-core on applicable Lenovo servers running Windows Server 2022.

At Lenovo Press, we bring together experts to produce technical publications around topics of importance to you, providing information and best practices for using Lenovo products and solutions to solve IT challenges.

See a list of our most recent publications at the Lenovo Press web site:

<http://lenovopress.com>

Do you have the latest version? We update our papers from time to time, so check whether you have the latest version of this document by clicking the **Check for Updates** button on the front page of the PDF. Pressing this button will take you to a web page that will tell you if you are reading the latest version of the document and give you a link to the latest if needed. While you're there, you can also sign up to get notified via email whenever we make an update.

Contents

Introduction	3
Supported Lenovo servers	6
Enabling Secured-core in UEFI	6
Enabling Secured-core in Windows Server 2022.	8
Confirming Secured-core is enabled	11
Resources	13
Author.	13
Notices	14
Trademarks	15

Introduction

A certified Secured-core server takes full advantage of hardware, firmware, driver, and operating system capabilities to enable advanced Windows Server 2022 security features to further protect the operating environment from the boot process through to data in memory.

The protections enabled by a Secured-core server are targeted to create a secure platform for critical applications and sensitive data used on that server and provide further assurance that the hypervisor or the operating system has not been tampered with and access to data in memory is protected.

The Secured-core functionality is built on the following distinct security components:

- ▶ Hardware root-of-trust with TPM 2.0
- ▶ Firmware Protection with DRTM
- ▶ Windows System Guard
- ▶ Virtualization-based Security (VBS)

These are discussed in the following sections.

Tip: Secured-core was first introduced in Windows Server 2022, and is a combination of security features implemented in hardware, firmware, driver and the operating system. However, there is no actual feature named “Secured-core”; instead, it is just a group of security-related settings in UEFI and in Windows that are enabled.

To be certified for Secured-core, new server firmware protection features are required. Currently only ThinkSystem servers with 3rd Gen Intel Xeon Scalable processors are certified, however ThinkSystem servers with AMD EPYC 7003 Series processors are also planned in the near future.

Hardware root-of-trust with TPM 2.0

Trusted Platform Module 2.0 (TPM 2.0) comes standard with Secured-core servers. A TPM 2.0 chip can check the integrity of the UEFI and firmware of the devices, comparing it to the information that has been burned into the chip by Lenovo during manufacturing.

This Secure Boot capability ensures that no unauthorized firmware or software has been loaded before the OS. It gives customers a secure store for sensitive keys and data during early boot process and the isolations from software-based attacks. This hardware root-of-trust provides a hardware level verification that the rest of the operating system and applications can rely on.

Figure 1 steps through a trusted boot process in which UEFI uses TPM to measure initial BIOS, Option ROMs, device drivers, and OS components prior to their execution by checking data integrity, consistent of PCR values or hash values. The boot process ensures that, when the OS loads and the user logs in, the system is trusted.

Tip: Measured boot is a way for OS to record the chain of measurements of software components and configuration information in the TPM through the initialization of the Windows operating system.




Figure 1 How Windows uses the Trusted Platform Module for measured boot

Firmware protection with DRTM

Firmware executes with high privileges and is often invisible to traditional anti-virus solutions, which has given rise to numbers of firmware-based attacks. Attackers compromise the boot flow to achieve low-level malware behavior that is hard to detect, posing a significant risk to systems.

To keep the server's firmware and hardware trustworthy and healthy, the server should be able to detect and block malicious software that runs before the operating system initializes or during the boot process itself.

There are two techniques to measure early boot UEFI components:

- ▶ Static Root of Trust for Measurement (SRTM)

SRTM provides a fixed piece of trusted code in the UEFI that is loaded at the start of the entire booting chain. SRTM has some shortcomings, however: the SRTM flow is brittle that a minor change can invalidate the chain of trust, and SRTM gives only the load time guarantee but not the run time guarantee for the launched environment.

- ▶ Dynamic Root of Trust for Measurement (DRTM)

DRTM is a trust mechanism using Intel's Trusted Execution Technology (TXT) or AMD's SKINIT technology to provide run time protection and guarantee. In contrast with the SRTM, DRTM has the advantage that the launch of the measured environment can occur at any time without resorting to a platform reset.

By leveraging built-in silicon instructions or firmware enclaves, DRTM allows the system to freely boot into untrusted code initially, but shortly after launches the system into a trusted state by taking control of all CPUs and forcing untrusted, exploitable code down a specific and measured code path before launching into a trusted state. Then the control of the DRTM environment is transferred to the Hypervisor and OS. The boot chain of trust is setup finally, then hypervisor or OS kernel can be booted securely.

Figure 2 shows the DRTM process works to secure the system.




Figure 2 Using DRTM to securely launch Hypervisor and OS

System Guard with Kernel DMA protection

PCIe devices are direct memory-addressing (DMA)-capable, which means they have direct access to read and write system memory, without having to involve the system processor in these operations. This DMA capability makes PCIe devices the highest performing devices, however, having PCI hot-plug devices (such as NVMe hot-swap drives) externally and easily accessible also means unattended device could have a malicious PCIe device plugged into it, which could read the system memory or load malicious code into it, with no protection.

This kind of “drive-by DMA attacks” using PCIe hot plug devices can lead to the disclosure of sensitive information residing on a system, or even the injection of malware that allows attackers to bypass the lock screen or control the system remotely. Kernel DMA Protection is the feature designed to protect the system against this type of attack.

Windows makes use of the system Input/Output Memory Management Unit (IOMMU) to block external peripherals from starting and performing DMA unless the drivers for these peripherals support memory isolation, such as DMA-remapping. DMA remapping restricts the device to a certain pre-assigned memory region, which confirms the device is allocated a clear space of memory to perform its functions and doesn’t have access to any other information stored in system memory. Devices whose drivers are incompatible with DMA remapping are prevented from direct memory access by default until an authorized user is logged onto the system.

Kernel DMA Protection requires the support from the processor, new UEFI firmware, and drivers. With this feature, the OS and the system firmware protect the system against malicious and unintended DMA attacks for all DMA-capable devices. Currently this feature is only available on ThinkSystem servers with 3rd Gen Intel Xeon Scalable processors although ThinkSystem servers with AMD EPYC 7003 Series processors are also planned to support the feature. Kernel DMA Protection only protects against drive-by DMA attacks after the OS is loaded.

Virtualization-based Security (VBS) support

Secured-core servers support virtualization-based security (VBS) features and Hypervisor-protected code integrity (HVCI) so as to leverage virtualization capabilities from hardware and the hypervisor to provide additional protection for critical subsystems and data.

VBS uses hardware virtualization features to create and isolate a secure region of memory from the normal operating system. VBS runs this separate secure kernel at a higher trust level than the actual Windows system kernel. Then the OS kernel and user-mode processes

cannot access the protected functions and data directly, thus protecting them from malware infection. VBS also allows for the use of Credential Guard to provide preventative defense for sensitive assets like credentials.

Hypervisor-based code integrity (HVCI) uses VBS to check the integrity of kernel mode drivers and binaries before they are started and prevents unsigned drivers or system files from being loaded into system memory. Enabled with HVCI, a Secured-core server only starts executables signed by known and approved authorities. This ensures that code running within the trusted computing base runs with integrity and is not subject to exploits or attacks.

Supported Lenovo servers

For Secured-core support, the servers must meet certain baseline hardware, firmware and software requirements. At the time of writing, the following Lenovo ThinkSystem servers and ThinkAgile™ MX system are certified as supporting Secure-core with Windows Server 2022:

- ▶ ThinkAgile MX3530
- ▶ ThinkAgile MX3531
- ▶ ThinkServer® SR590 V2
- ▶ ThinkSystem SD630 V2
- ▶ ThinkSystem SN550 V2
- ▶ ThinkSystem SR630 V2
- ▶ ThinkSystem SR650 V2
- ▶ ThinkSystem SR670 V2
- ▶ ThinkSystem ST650 V2

To get the current list of certified Lenovo server, go to the following URL:

<https://www.windowsservercatalog.com/results.aspx?&bCatID=1333&cpID=23292&avc=132&ava=0&avt=0&avq=140&OR=1&PGS=25>

Enabling Secured-core in UEFI

This section describes the UEFI settings to enable the Secured-core feature on ThinkSystem servers.

To enable Secured-core, you need the support from the UEFI firmware, so ensure the firmware version installed in your system can fulfill this requirement, as listed in Table 1 on page 6.

Table 1 Minimum firmware levels for Secured-core support

Servers	Minimum firmware level
ThinkSystem SR650 V2 ThinkSystem SR630 V2	Build ID AFE114D or newer
ThinkSystem SD630 V2 ThinkSystem SN550 V2 ThinkSystem SR670 V2 ThinkSystem ST650 V2	Build ID U8E114E or newer
ThinkAgile systems	Build ID AFE114G (use the guidance in the current Best Recipe document)
ThinkServer SR590 V2	Build ID XWE140N or newer

For the latest UEFI firmware, go to the Lenovo support site:

<https://datacentersupport.lenovo.com/us/en/products/servers/thinksystem>

For SR590 V2, use the following site:

<https://datacentersupport.lenovo.com/cn/zc>

To support Secured-core you will need to set the following UEFI items.

1. Enable Secure boot in UEFI settings via **System Settings** → **Security** → **Secure Boot Configurations** → **Secure Boot** as shown in Figure 3.




Figure 3 Enable Secure boot

2. Enable TPM 2.0 in UEFI settings via **System Settings** → **Security** → **Secure Boot Configurations** → **Trusted Platform Module** → **TPM 2.0** as shown in Figure 4.




Figure 4 Enable TPM 2.0

3. Enable Intel TXT in UEFI settings via **System Information** → **Socket Configuration** → **Processor Configuration** → **Enable Intel TXT** as shown in Figure 5.




Figure 5 Enable Intel TXT

4. Enable Intel VT-d and DMA protection in UEFI settings via **System Setting** → **Devices and I/O Ports** → **Intel VT for Directed I/O (VT-d)** and **System Setting** → **Devices and I/O Ports** → **DMA Control Opt-In Flag** as shown in Figure 6.




Figure 6 Enable Intel VT-d and DMA protection

Enabling Secured-core in Windows Server 2022

After the UEFI setting is ready for Secured-core support, you will need to enable settings in the operating system.

There are two ways to set up the Secured-core in Windows Server 2022:

- ▶ “Enabling Secured-core using the Windows Security GUI”
- ▶ “Enabling Secured-core using PowerShell commands” on page 11

Enabling Secured-core using the Windows Security GUI

To enable Secured-core by using the Windows Security App (Windows Server with Desktop experience only), perform the following steps:

1. Launch the Windows Security app from the Start menu, Figure 7.




Figure 7 Launch Windows Security App

2. Choose **Device security**, Figure 8.




Figure 8 Device security

3. Click **Core isolation details** as shown in Figure 9.




Figure 9 Core isolation details

4. Set both **Memory integrity** and **Firmware protection** to On, Figure 10.




Figure 10 Enable Memory Integrity and Firmware Protection

If Memory Integrity or Firmware Protection cannot be set to On, it means the system doesn't meet the requirement for this enhanced security feature. Check that the UEFI version meets requirements and UEFI settings are ready as described in "Enabling Secured-core in UEFI" on page 6. Secured-core is not supported in any older Windows Server versions such as Windows Server 2019.

Secured-core in virtual machines: Currently Secured-core is not supported in VMs. Kernel DMA protection and Secure Launch are technologies for hardening host hardware and are not applicable to VMs. Therefore, in VMs Memory Integrity or Firmware Protection fails to be set to On.

5. Reboot the system to make the changes take effect.

Enabling Secured-core using PowerShell commands

Use the following three PowerShell commands to enable Secured-core, Figure 11

```
reg add "HKLM\SYSTEM\CurrentControlSet\Control\DeviceGuard\Scenarios\HypervisorEnforcedCodeIntegrity" /v "Enabled" /t REG_DWORD /d 1 /f

reg add "HKLM\SYSTEM\CurrentControlSet\Control\DeviceGuard\Scenarios\HypervisorEnforcedCodeIntegrity" /v "WasEnabledBy" /t REG_DWORD /d 0 /f

reg add "HKLM\SYSTEM\CurrentControlSet\Control\DeviceGuard\Scenarios\SystemGuard" /v "Enabled" /t REG_DWORD /d 1 /f
```


Figure 11 PowerShell commands to enable Secured-core

After these registry settings are finished, a system reboot is required to make the changes take effect.

Confirming Secured-core is enabled

To confirm all the Secured-core features are properly configured and running, follow the steps below:

1. To confirm TPM 2.0 is enabled, issue **get-tpm** in a PowerShell and confirm that TpmPresent, TpmReady, TpmEnabled and TpmActivated are all "True" as shown in Figure 12.




```
PS C:\Users\Administrator> get-tpm

TpmPresent           : True
TpmReady             : True
TpmEnabled           : True
TpmActivated         : True
TpmOwned             : True
```

Figure 12 TPM 2.0 check

2. To check that Secure Boot is enabled, start **msinfo32** and in the System Summary page, verify that Secure Boot State is set to On, as shown in Figure 13.



Secure Boot State	On
PCR7 Configuration	Not Available
Windows Directory	C:\Windows
System Directory	C:\Windows\system32
Boot Device	\Device\HarddiskVolume1
Locale	United States
Hardware Abstraction Layer	Version = "10.0.20348.143"

Figure 13 Secure Boot check

- In the Windows Server GUI, go to **Windows security** → **Device security** → **Core isolation** and verify that Memory Integrity and Firmware Protection are set to On, as shown in Figure 14.




Figure 14 Memory Integrity and Firmware Protection check

- Verify that Kernel DMA Protection, VBS, HVCI and Secure Launch are enabled, by starting msinfo32 and checking the System Summary page for the following values, as shown in Figure 15 on page 12:
 - **Kernel DMA Protection** is On
 - **Virtualization-Based Security** is Running
 - **Virtualization-Based Security Services Configured** contains the value Hypervisor enforced Code Integrity, Secure Launch
 - **Virtualization-Based Security Services Running** contains the value Hypervisor enforced Code Integrity, Secure Launch




Figure 15 Kernel DMA Protection, VBS, HVCI and Secure Launch check

If all the Secured-core features above are properly configured and running, it means Secured-core feature is working well in your system and you can benefit from this feature to protect your critical applications and sensitive data.

Resources

- ▶ Lenovo drivers for Windows
<https://windows-server.lenovo.com/repo/latest/>
- ▶ Microsoft web page for Secured-core
<https://docs.microsoft.com/en-us/windows-server/security/secured-core-server>
- ▶ Microsoft web page for new features in Windows Server 2022
<https://docs.microsoft.com/en-us/windows-server/get-started/whats-new-in-windows-server-2022>
- ▶ Microsoft web page for Kernel DMA protection (KDMA)
<https://docs.microsoft.com/en-us/windows/security/information-protection/kernel-dma-protection-for-thunderbolt>
- ▶ Microsoft web page for Dynamic Root of Trust for Measurement (DRTM)
<https://www.microsoft.com/security/blog/2020/09/01/force-firmware-code-to-be-measured-and-attested-by-secure-launch-on-windows-10/>
- ▶ Microsoft web page for Trusted Platform Module
<https://docs.microsoft.com/en-us/windows/security/information-protection/tpm/how-windows-uses-the-tpm>
- ▶ Microsoft web page for Virtualization-based Security (VBS)
<https://docs.microsoft.com/en-us/windows-hardware/design/device-experiences/oem-vbs>

Author

Guiqing Li, a Windows Engineer at the Lenovo ISG in Beijing, China. She has more than ten years of experience with driver development, and five years of experience with Windows debugging.

Special thanks to the following specialist for their contributions and suggestions:

- ▶ Vinay Kulkarni, Lenovo Principal Technical Consultant
- ▶ Gary Cudak, Lenovo OS architect for OS Enablement and Preload
- ▶ Boyong Li, Lenovo Windows Engineer for Windows Enablement
- ▶ David Watts, Lenovo Press

Notices

Lenovo may not offer the products, services, or features discussed in this document in all countries. Consult your local Lenovo representative for information on the products and services currently available in your area. Any reference to a Lenovo product, program, or service is not intended to state or imply that only that Lenovo product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any Lenovo intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any other product, program, or service.

Lenovo may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

Lenovo (United States), Inc.
1009 Think Place - Building One
Morrisville, NC 27560
U.S.A.
Attention: Lenovo Director of Licensing

LENOVO PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. Lenovo may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

The products described in this document are not intended for use in implantation or other life support applications where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Lenovo product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Lenovo or third parties. All information contained in this document was obtained in specific environments and is presented as an illustration. The result obtained in other operating environments may vary.

Lenovo may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any references in this publication to non-Lenovo Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this Lenovo product, and use of those Web sites is at your own risk.

Any performance data contained herein was determined in a controlled environment. Therefore, the result obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

This document was created or updated on March 31, 2022.

Send us your comments via the **Rate & Provide Feedback** form found at <http://lenovopress.com/lp1578>

Trademarks

Lenovo and the Lenovo logo are trademarks or registered trademarks of Lenovo in the United States, other countries, or both. These and other Lenovo trademarked terms are marked on their first occurrence in this information with the appropriate symbol (® or ™), indicating US registered or common law trademarks owned by Lenovo at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of Lenovo trademarks is available from <https://www.lenovo.com/us/en/legal/copytrade/>.

The following terms are trademarks of Lenovo in the United States, other countries, or both:

Lenovo®	ThinkAgile™	ThinkSystem™
Lenovo (logo)®	ThinkServer®	

The following terms are trademarks of other companies:

Intel, Xeon, and the Intel logo are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Microsoft, PowerShell, Windows, Windows Server, and the Windows logo are trademarks of Microsoft Corporation in the United States, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.